



## Reorganization of discharge pipes.

Use of BIO SPIRAL with nearly complete blockage.

Let the indicated mixtures approx. 30-45 min. stand before you are introduced.

Do not rinse after the introduction about 6-8 hours if possible.

(At least 4-6 hours)

Diameter discharge pipe	Pipe length	Dosage 5 days successively
50 mm	5-30 meters	Mix 2 measuring spoons with 0,5 litres water
50 mm	30-90 meters	Mix 1/8 box with 2 litres water
70 mm	5-30 meters	Mix 4 measuring spoons with 1 litre water
70 mm	30-90 meters	Mix 1/4 box with 4 litres water
100 mm	5-30 meters	Mix 6 measuring spoons with 2 litres water
100 mm	30-90 meters	Mix 1/2 box with 8 litres water
125 mm	5-30 meters	Mix 8 measuring spoons with 3 litre water
125 mm	30-90 meters	Mix 3/4 box with 10 litres water
150 mm	5-30 meters	Mix 10 measuring spoons with 4 litres water
150 mm	30-90 meters	Mix 1 box with 12 litres water
200 mm	5-30 meters	Mix 1/4 box with 6 litres water
200 mm	30-90 meters	Mix 1 1/4 box with 20 litres water

**Repeat those procedure after 5 days successively 1 time the week.**

**After approximately 8-12 weeks should be reorganized the pipings.**

**[www. BIO-SPIRAL.de](http://www.BIO-SPIRAL.de)**